


Bike Rack Installation Instructions

Cora Bike Rack - E3VR45-R and E3VR45-L



2. Mounting height of single or multiple adjacent racks (E3VR45-L or E3VR45-R)







Bike Rack Installation Instructions


Cora Bike Rack - E3VR45-R and E3VR45-L


5. Fasten rack to wall (Either E3VR45-R or E3VR45-L)





6. Access and clearance around mounted racks





Access dimensions around racks

- Racks are to be mounted with minimum clearance zones from any wall a rack is mounted to
- Min. 850mm from wall for bike clearance & minimum 1500mm (diagonal) additional for access aisle
- For E3VR45 racks, To comply with AS2890.3 (2015) minimum 500mm spacing between bikes, racks to be mounted at 710mm centers











PH 1800 249 878

sales@cora.com.au www.cora.com.au